




APC-KP1-C Quick Wiring and Programming


APC-CBSW 12 & APC-CBSW 24 Swing Gate Connection






APC-CBSG 12 Sliding Gate Connection





Quick Programming Pin Code



Master Code used to enter programming only


To enter Pin code programming

Any number between 1-999, this number is unique to each pin code/swipe tag and cannot be used twice

The Pin code you would like to use to open the gate (4-6 Digits)

To Exit programming and return to standby state

Quick Programming Swipe Tag



Master Code used to enter programming only

To enter Pin code programming

Any number between 1-999, this number is unique to each pin code/swipe tag and cannot be used twice

Swipe the tag past the black APC window

To Exit programming and return to standby state